

**ZANUSSI**

---

# **Instructions for the use and care of your ID 500/ID 503 Dishwasher**

---

# Contents

# Technical data

## Installation

Positioning	Page 3
Levelling	Page 3
Water Connection	Page 3
Electrical Connection	Page 5

## Operation

Control Panel Description	Page 6
Loading the Crockery	Page 7
Loading the Rinse Aid	Page 9
Loading the Detergent	Page 10
Water Softener	Page 11
Washing Programmes	Page 12
Washing Programmes	Page 13
Starting the Machine	Page 14
Stopping the Machine	Page 14

## Care and cleaning

Cleaning the Filter	Page 14
Cabinet Cleaning	Page 16

## Useful Hints

Something not working	Page 17
-----------------------	---------

Building-in instructions	Page 18
--------------------------	---------

Width	60 cms.
Overall Depth	57 cms.
Overall Depth with Open Door	115 cms.
Height without Worktop	82 cms.
Capacity (in standard IEC place settings)	12
Supply Voltage	220/240 V - 50 Hz
Motor rating during Washing	250 W
Heating Element Power	2570 W
Max. Power Absorbed	2820 W
Water Supply Pressure minimum	7 p.s.i. - 49 kN/m <sup>2</sup>
maximum	110 p.s.i. - 758 kN/m <sup>2</sup>

# Installation

## Positioning

After removing the outer carton, set up the machine in the selected spot, preferably very close to water loading and draining facilities. Furthermore, the machine can be installed with the sides and back in touch with the adjacent furniture or with the wall.

The dishwasher features fill and drain hoses which can be turned either to the right or to the left (fig. 1) to suit the installation.

The machine can be installed under the kitchen counter or under the sink (see page 18).

## Levelling

The machine should be accurately levelled by adjusting the four levelling feet so that it be perfectly level (max. allowed error  $\pm 2^\circ$ ). An accurate levelling is a must to ensure a correct operation of the machine.

## Connecting to the water supply

The machine may be supplied with either cold or hot water. **In the latter case, make sure that the temperature of the hot water never exceeds 60°C (140°F).**

The inlet hose should be connected to a 3/4" gas thread spout (fig. 2-3) or to a quick-coupling tap (Press-Block) after inserting the special strainer A supplied with the machine.

Make sure that the water supply pressure is within the limits indicated under the technical data (page 2).




Fig. 1




Fig. 2




Fig. 3

## Water outlet connection (fig. 4-5)

The drain pipe from this machine must connect into the main drain from the premises, but not into the rainwater drain. Information as to the type of drain servicing your premises can be obtained from a builder or the Local Authority.

The outlet hose should be firmly hooked over the edge of a sink or connected to a suitable drain pipe in the wall or under the sink; however, such a drain pipe should have a built-in air break in order to avoid water syphoning from the machine during draining. The top of the drain hose should not be lower than 30 cms (12 ins) or higher than 90 cms (36 ins) from floor level.

The water should be able to drain freely and the end of the outlet hose must not be under water. It is, therefore, advisable that the drain pipe, if used, has an internal diameter of at least 4 cms (1.5 ins). Also, ensure that the drain hose is not choked or placed in such a way as to obstruct the normal water flow.

If the drain hose is to be hooked over the sink, ensure that the sink is empty and that the sink plug is not blocking the plug hole. If an extension is required, its inner diameter must be the same as that of the original hose of the washer and its length must not exceed 2 metres (6 ft).




Fig. 4




Fig. 5

# Electrical connection

## WARNING: THIS APPLIANCE MUST BE EARTHED

**The manufacturer declines to accept any liability should this safety measure not be observed.**

**Important:** The wires in this mains lead are coloured in accordance with the following code:

GREEN AND YELLOW - EARTH,  
BLUE-NEUTRAL, BROWN - LIVE

If you fit your own plug, the colours of the wires in the mains lead of your appliance may not correspond with the markings identifying the terminals in your plug; this is what you have to do: Connect the green and yellow (earth) wire to the terminal in the plug which is marked with the letter **E** or the earth symbol  $\perp$ , or coloured green, or green and yellow.

Connect the blue (neutral) wire to the terminal in the plug which is marked with the letter **N** or coloured black.

Connect the brown (live) wire to the terminal which is marked with the letter **L** or coloured red.

If the plug is not suitable it must be cut off and the appropriate plug fitted.

The cut off plug should be disposed of to prevent the hazard of electric shocks in case it should be plugged into a 13 Amp socket in another part of your home.

The plug moulded on to the cord incorporates a fuse. For replacement, use a 13 Amp BS 1362 fuse. Only ASTA approved fuses should be used. The fuse cover/carrier must be replaced in the event of changing fuse.

The right fuse cover/carrier colour is the one shown by the coloured insert at the base of the plug.

The plug must not be used if the fuse cover/carrier is lost.


A replacement cover/carrier must be obtained from Zanussi Service Agents whose addresses are listed on the attached «Zanussi Service Agents Nationwide».

**This appliance complies with E.E.C. directive No 76/889 of 4.11.76 relative to radio interference suppression.**

# Operation

## Control panel

- 1 START & STOP Switch
- 2 Water Temperature Pushbutton
- 3 Economy Drying Pushbutton
- 4 «Machine-live» Indicator
- 5 Door Handle
- 6 Salt Refilling Indicator
- 7 Programme Selector
- 8 Wash Cycle Phase Indicator



### Programme Selector

This control permits selection of the required wash cycle. Turn the knob clockwise until the index points exactly on the proper letter of the required wash cycle.

### Economy Drying Pushbutton

When depressed, it excludes the final hot-air drying phase. Drying will take a little longer, but the energy consumption will be reduced.

### Water Temperature Pushbutton

This pushbutton permits selection of the required water temperature. When depressed, it will cause the water to heat up to 55°C. By depressing it again and thus releasing this pushbutton, the wash water will heat up to 65°C.

### START & STOP Switch

By depressing this pushbutton the machine starts operating and, at the same time, the pilot lamp will light up. When depressing it again, the machine stops and the pilot lamp goes out.

### Attention

Once this pushbutton is depressed, it is no longer possible to modify the setting of the other pushbuttons insofar as a mechanical safety locking device is actuated by the START & STOP pushbutton.

Therefore, when going through the various steps to select the programme, the START & STOP pushbutton should be absolutely the last one to be depressed.

### Door Handle

Grip it firmly, pull it outwards. To close the door, simply push it back till it engages.

### Salt Refilling Indicator

It tells you when the time has come to refill the salt in the container (see page 11).

### Loading the crockery

Prior to arranging the crockery in the baskets, do remove the bigger food scraps (such as tiny bones, fish-bones, meat or vegetable scraps, fruit peels, etc.) to prevent the filter from clogging, which would cause poor washing results.

Open the door and slide out the baskets to be able to load the crockery.

### Using the bottom basket (fig. 6-7)

The lower basket is designed to take pots, dishes, salad-bowls, cutlery, etc. The cutlery should be placed into the special small removable basket. To obtain good washing results, it is recommended to intermix spoons with knives and forks so that they will not stick together.

We also suggest that you stack the cutlery into the special small basket with the handles facing downwards. However, if the handles of your cutlery are very thin it is advisable to stack the cutlery with the handles facing upwards, so as to prevent them from sticking out from the bottom of the small basket and thereby blocking the lower spray arm.




Fig. 6




Fig. 7

## Using the top basket (fig. 8-9)

The top basket is designed to take dishes (dessert plates, saucers, flat plates, soup plates) up to a 24-cm. diameter plus cups and glasses which should be arranged as shown in the respective pictures.

### Top basket raising & lowering

If very big plates (over 27 cms. and up to 31 cms. in diameter) are normally used, the top basket will have to be raised to the upper position. This will make it possible to properly arrange these extra large plates in the bottom basket. To raise the top basket, remove the basket itself after taking off the front runner stops (fig. 10), remove the slides (B - fig. 11) after taking off the rear runner stops and refit them on the higher position (A - fig. 11), then replace the rear runner stops, the top basket and, finally, the front runner stops.

With the top basket on this upper position there is of course less loading clearance in the basket itself (which will in fact only take dishes up to 19 cms.) and this will also prevent utilization of the basket's raised cup compartments.

### Important

When loading the crockery be absolutely sure not to accidentally obstruct the water inlet funnel at the centre of the upper basket.

Only a correct loading of the dishwasher will ensure good washing results.

After loading the crockery, make sure that the spray arms turn freely.



Fig. 8




Fig. 9




Fig. 10






Fig. 11




Fig. 12

## Jet strength control

The water jet strength of the upper spray arm can be adjusted by turning the water inlet funnel as shown in the picture (A - fig. 12) to obtain the best washing results without risking that particularly light crockery is upset by the jets:

- + jet strength increase
- jet strength decrease.

## Loading the rinse aid

The rinse aid dispenser, which automatically dispenses the right amount of rinse aid at the proper time, is located inside the dishwasher door. This special liquid product is essential to ensure prompt drying of the crockery and to make it come out crystal-clear since it prevents formation of stains due to the salts contained in the water.

## Filling

Press catch A (fig. 13) to open the container lid.

Pour the rinse aid into the funnel. The container holds approx. 150 cu. cms. of rinse aid, which will last for about 70 wash cycles.

The level can be checked through the level indicator B (fig. 14).

## Quantity

The quantity of rinse aid dispensed automatically from the container can be adjusted, in each single case, to compensate for hard or soft water, more being required for hard water and less for soft.

The quantity can be adjusted by means of knob C (fig. 14).




Fig. 13

## Important

We would suggest that you initially leave the knob on the preset position; only after a few wash cycles, if need be, should you increase the quantity of dispensed rinse aid if the crockery remains dull or shows occasional round spots.

## Loading the detergent

The washing powder should be poured into compartment **D** of the container located on the inner door (fig. 15). If the lid of the container happens to be closed, to open it simply push back catch **E** which keeps it clamped down.

**Quantity of Detergent:** the quantity to be loaded depends on the brand used, on the degree of soil and type of load. On the average, we recommend 4 teaspoonfuls (25 grams) if you have to wash normally soiled crockery, and up to 5 teaspoonfuls (30 grams) for heavily soiled crockery.

Also take into account the detergent manufacturer's recommendations. After loading the detergent in the proper compartment, close the lid. The detergent will be automatically dispensed at the proper time.

## Important

Only use detergents specially made for dishwashers.

To obtain fine washing results you should only use top quality detergents.

An insufficient quantity of detergent will give poor washing results, whereas an excessive quantity will not improve the results but will only represent a waste.




Fig. 14




Fig. 15



Fig. 16

## Water softener

Depending on the area, water contains more or less limestone and mineral salts which tend to deposit on the crockery forming whitish markings that eventually cause all surfaces to become dull. The dishwasher incorporates a water softener which purifies the water of all limestone for dishwashing.

In this way the cleaning action is greatly enhanced, no incrustations form and during the rinsing phases the crockery is restored to its original brilliance.

Operation of the water softener is completely automatic.

## Salt refilling

After unscrewing the cap, fill 1,5 kg of coarse cooking salt using the funnel supplied with the machine into the container on the tub bottom (fig. 16).

Carefully replace the container screwcap, making sure that the threading and the gasket have no trace of salt.

After this, it will suffice to periodically top up the container with salt only.

To remind you of this operation, the machine incorporates a salt refill indicator (6 - page 6) graduated from number 1 to 20.

Following each wash cycle carried out, the indicator inches forward by one number so that, when the highest number (20) is reached, it means that salt has to be refilled even if the supply is not completely depleted.

## Important

**When the appliance is put into operation for the first time, it is recommended that you carry out a complete wash cycle without loading any salt in the respective container. All salt refilling and topping up operations should be carried out immediately prior to starting any one of the complete wash cycles (with the exception of the RINSE & HOLD**

programme) in order to prevent the possibility that any salt granules or salt water, which might flow out of the salt container during refilling of the same, remain for some time on the bottom of the wash tub without being properly diluted.

Use only coarse cooking salt or specific equivalent products for water softeners.

## Adjusting the water softener

The water softener is preset for water having a maximum hardness of 40°F (22°d). This setting is designed to suit most of the field requirements.

At any rate, if the water hardness exceeds 40°F (up to a maximum of 60°F), the water softener may be adjusted accordingly.

This operation should be carried out by qualified personnel who should proceed as follows:

Pull out the dishwasher from its recess. Drill (pierce) a 1-2 mm. vent hole on point A of the plastic tank as shown in fig. 17.

Put the dishwasher back in its recess. Make sure the fill and drain hoses are not kinked.

Under normal operating conditions, the supply of salt in the container will last for about 20 wash cycles, whereas by



Fig. 17

# Washing programmes

Programme Type of load and  
degree of soil

---

**1**

Extremely soiled  
crockery, pots, pans  
and cutlery

---

**2**

Normally soiled crockery,  
pots, pans and cutlery,  
with a normal quantity  
of food scraps

---

**3**

Normally soiled crockery,  
pots, pans and cutlery,  
with a reduced  
quantity of food scraps

---

**4**

Lightly soiled crockery,  
pots, and cutlery

---

**5**

Normally soiled crockery,  
plates and saucers,  
glasses and cutlery

---

**6**












Lightly soiled dishes  
and glasses with  
delicate decorations

---

**7**

Partial load (to be  
completed  
later in the day)

---

Recommended programme	Programme knob setting	Required pushbutton	Cycle description
Energetic with prewash	<b>A</b>		Cold prewash / Extended main wash up to 65°C / 2 cold rinses / 1 hot rinse / hot air drying
Universal with prewash	<b>C</b>		Cold prewash / Main wash up to 65°C / 2 cold rinses / 1 hot rinse / hot air drying
Universal no prewash	<b>D</b>		Main wash up to 65°C / 2 cold rinses / 1 hot rinse / hot air drying
Economy with prewash	<b>A</b>	 	Cold prewash / Extended main wash up to 55°C / 2 cold rinses / 1 hot rinse / hot air drying
Economy no prewash	<b>B</b>	 	Extended main wash up to 55°C / 2 cold rinses / 1 hot rinse / hot air drying
Gentle no prewash	<b>D</b>	 	Main wash up to 55°C / 2 cold rinses / 1 hot rinse / hot air drying
Rinse & hold	<b>F</b>		Cold rinse to prevent food scraps from drying up and sticking to the dishes.
Economy Drying			Press button if required.

making the above-mentioned inlet hole, the salt supply will only last for half as many wash cycles.

Therefore, the salt will have to be refilled in the respective container every time the salt refill indicator shows number 10 and number 20 respectively.

## Starting the machine

After connecting the machine to the water supply and to the electric power supply, close the door and then proceed as follows.

Turn the programme selector knob to the required setting.

Depress the pushbuttons as required, if any (2-3 page 6).

Depress the START pushbutton (1 page 6).

At this point the pilot lamp will light up and the machine starts operating.

## Stopping the machine

When the wash cycle is completed the machine stops automatically but the pilot lamp remains alight and to turn it off the STOP pushbutton has to be depressed.

If you require to stop the machine at any moment during the wash cycle, simply depress the aforementioned STOP pushbutton. To restart the machine, depress again the same pushbutton and the wash cycle will resume from where it was interrupted. It is not advisable to open the door during operation. At any rate, the machine incorporates a safety device which stops operation when the door is opened.

We would also recommend, at the end of a wash cycle, that you turn off the water tap and unplug the machine from the wall socket.

# Care & cleaning

## Cleaning the filter assembly

The filter assembly consists of a large circular fine-mesh filter (A) and two small cone shaped filters (B-C), fitting one within the other, both being housed in the large filter (fig. 18).

We recommend that you inspect the two small filters B and C after each wash cycle, removing any food scraps that you might detect.

These two concentric filters can be removed by slightly turning the outer filter B anticlockwise until it disengages from its seat (fig. 18).

To remove the inner filter C, squeeze together the two small plastic tongues (fig. 19) sticking out from the bottom of outer filter B.

The large fine-mesh filter (A) should be cleaned from time to time (roughly once every two months) on both sides with a suitable brush.

To remove this large filter (A), take off the bottom sprayarm and unlock part D fig. 20.

Replace the assembly reversing the above procedure, making sure that the outer rim of the circular filter fits correctly in its housing on the tub bottom.

The dishwasher should not be operated without the filters being correctly installed.

Periodic cleaning of the filters is essential for a smooth and efficient operation of the machine.




Fig. 18

## Cleaning the sprayarm nozzles

The holes of the sprayarm nozzles should not be obstructed as this would greatly reduce the effectiveness of the washing cycle.

To remove the bottom sprayarm release it from its securing catches and pull it out. To clean the nozzles of the top sprayarm, slide out the top basket whereby the sprayarm will become perfectly accessible.

To remove it, disengage conveyor A from its coupling and unscrew ring nut B (fig. 21).

## Cleaning the door gasket

Use a soft damp cloth to clean the door gaskets.

The bottom gasket can be slightly raised to clean the part of tub below it.



Fig. 19



Fig. 20




Fig. 21

## Cabinet cleaning

The outer cabinet and the control board in particular should be wiped periodically with a soft damp cloth and, if necessary, with a little neutral detergent.

To clean these parts, never use abrasive products which might scratch the surface.

## Long idle periods

If the machine is not to be used for some time, it is advisable to take the following precautions:

Disconnect the machine from the electrical network and from the water supply;

Fill up the rinse aid container;

Leave the door ajar to prevent bad smells from lingering in the machine;

Leave the inner part of the machine clean, even if there is some crockery left, by carrying out at least a rinse & hold programme (No. 7).

## If you are moving

If you are moving and the dishwasher is transferred to a new location, make sure that the machine is not tilted too much during transport.

# Useful hints

It stands to reason that a machine of this standing should be utilized and exploited rationally and to its full capacity to make the most of it. Therefore, place the crockery in the machine immediately after the meals, conveniently arranging the various pieces in the respective compartments. If only partial loads are placed in the machine, do carry out a rinse & hold programme until the load is completed later in the day.

We would also suggest that you take into account the capacity and the space availability of your dishwasher when buying new crockery, particularly pots and pans, all of which should be suitable to be washed in the dishwasher.

**Pots:** this machine will also wash pots. Needless to say, the washing results depend on how soiled the pots are. If there are plenty of dried up food scraps or if there are burnt scraps, it is advisable to pre-rinse the pots by hand or to pre-soak them so as to loosen the scraps.

**Cutlery:** as a rule, you should not wash in the dishwasher cutlery having wooden or horn handles or glued parts which will not withstand hot water.

**Silver Cutlery:** this may be washed in the dishwasher with very good results, provided it does not come in touch with steel cutlery. The fact is that the oxidizing effect of the soapy water might cause unsightly spots due to the chemical interaction between the two metals.

Therefore, they should be arranged separately in the cutlery basket.

**Aluminium Ware:** Aluminium is not very suitable for dishwashing.



**Decorated Chinaware:** some decorations might fade when machine-washed, just as it sometimes happens when washing it by hand, and we would therefore suggest that you wash one single piece a number of times in the machine and then compare it with the other pieces to see if the decoration has faded. At any rate, use only programme number 6 for such delicate crockery.

**Crystalware and Plastic Ware:** if these are not certified to withstand machine washing you had better wash them by hand to play it safe.

# Something not working

If there is a malfunction, make the following checks before you call for service: it may save you trouble and expense.

## **The Machine will not start**

check that:

the door is correctly closed;

the water tap is full open;

the plug is perfectly inserted in the wall socket;

the fuses of the wiring system are not blown.

## **The machine will not drain**

check that:

the drain hose is not kinked (bent);

the filter is not clogged.

## **The crockery does not come out clean**

check that:

the detergent used is suitable for dishwashers and the quantity dispensed is the right one;

the crockery is correctly arranged in the baskets;

the sprayarms turn freely and the nozzles are not obstructed;

the filter is clean.

## **There are limestone deposits on the crockery**

check that:

there is enough salt in the container;

the rinse aid supply is not depleted;

the quantity of rinse dispensed is not insufficient.

There are traces of tea, coffee or lipstick left on the crockery  
check that:  
the quantity of detergent loaded in the machine is not insufficient.

# Building-in Features

This dishwasher is designed to be fitted under a kitchen counter or sink, alternatively to be completed with a specially made work-top.  
In either case, it is essential that the recess dimensions indicated in Fig. 23 are followed. The recess ceiling may be anywhere between 820 and 870 mm from the floor inasmuch as the dishwasher incorporates levelling feet adjustable over a wide range.




Fig. 22




Fig. 23




Fig. 24

To adjust the machine to the maximum height, unscrew and remove the feet. Then screw on the enclosed screw nuts and washers, as shown in drawing 24, and refit the feet.

Adjust the height and tighten the screw nuts.

No special openings or systems are required to permit ventilation of the machine, but only to let the electric supply cable and the water fill and drain hoses through.

When building the machine into a kitchen unit, make sure that these water fill and drain hoses are not bent or kinked.

The back of the machine may rest directly against the rear wall of the recess.

### Important:

When the dishwasher is secured to the kitchen cabinets, be sure not to drill any holes into the sides of the machine to avoid damaging the hydraulic components located between the wash tub and the cabinet.

To connect the machine to the electricity and water supply, be sure to follow the rules and regulations detailed in the operator's handbook that comes with the appliance.

It is absolutely essential that the appliance is disconnected from the electricity supply before gaining access to any internal component.

### Fitting the decorative panel to the door

The dishwasher door is designed to permit installation of a decorative wooden panel having a thickness of 2 cms.

### Preparing the panel

Determine the height of the control board depending on the height of the drawers of the adjacent kitchen cabinets and, if this height is to be more than 120 mm, add one or two of the supplementary wooden strips (Fig. 25).




Fig. 25




Fig. 26

Measure distance «a» between the control board and the reference notch on the door (Fig. 26).

Fix the supporting transoms to the panel, keeping the same distance «a» between the upper edge of the panel itself and the reference notch on the supporting transom (Fig. 26). The center distance between the tub transoms is 517 mm. It is advisable to first fix the transoms by means of flathead screws through the slot holes only, and then to make a trial fitting of the panel onto the door.

## Installing the panel on the door

Install the panel by engaging the bottom pins first, and then insert the top hooks of the transoms into the pins of the connecting rods as shown in Fig. 27.

Open the dishwasher door and check that during its rotation the decorative panel does not interfere with the control board.

In case of interference, increase the gap between the control board and the decorative panel by pushing the latter downwards.

As soon as the correct position has been found, remove the decorative panel from the dishwasher door, screw the supporting transoms tight and then reinstall the panel by going through the previously described steps.




Fig. 27





Fig. 28

## Fitting and securing under a counter (kitchen sink or counter)

To fit the dishwasher under a kitchen sink proceed as follows:

insert the appliance under the sink after correctly adjusting its height and levelling it as required by means of its adjustable levelling feet;

secure the mounting brackets (A - Fig. 28) to the front part of the dishwasher and sink by means of screws.




**Fig. 29**

In case of fitting under a kitchen counter, the two front mounting brackets must be secured to the counter work-top as shown in Fig. 29.

## Adjusting the door balance

Fitting the decor panel may sometimes affect the door balance due to the different load placed on the same. In this case it will be necessary to adjust the balance as follows:

loosen the screws A (see Fig. 30) securing the balancing brackets and shift the latter downwards; this will increase tension of the two door balancing springs; when the correct adjustment has been obtained, retighten the two screws.



**Fig. 30**





---

## ZANUSSI GUARANTEE CONDITIONS

This guarantee is in addition to your statutory and other legal rights which will not be excluded or in any way diminished by the return of the enclosed card.

We, IAZ International (UK) Ltd, guarantee that if within twelve months of the date of the purchase, this ZANUSSI appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials we will at our option repair or replace the same **FREE OF ANY CHARGE** for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity supply stated on rating plate.
- The appliance has been used for normal domestic purposes and in accordance with the manufacturer's operating and maintenance instructions.
- The appliance has not been serviced, maintained, repaired, taken apart or tampered with by any person not authorised by us.

- The appliance is still in the possession of the original purchaser.
- Any appliance or defective part replaced shall become our property.

This guarantee does not cover any damage caused during transportation or the replacement of any light bulbs or removable parts of glass or plastic.

Should you require service on your Zanussi appliance consult the enclosed list for your nearest Zanussi network centre. If the product is under first year guarantee then you will be required to produce proof of date of purchase to the engineer. If it is under 5 year cover then you must show your cover card to the engineer.

Please ensure that the enclosed pre-addressed card is stamped, completed in full and forwarded to IAZ International (UK) Ltd, to enable the guarantee to be recorded. Also complete the space below as your own record of the guarantee.

---

## GUARANTEE RECORD

Appliance purchased from \_\_\_\_\_ on \_\_\_\_\_

Guarantee card no \_\_\_\_\_ Model no \_\_\_\_\_

Serial no \_\_\_\_\_ (These details may be taken from your Guarantee Record Card)

Your name \_\_\_\_\_

Address \_\_\_\_\_

---